



HOBO[®] CABLE-RX-PWR

External DC Power Cable for RX3000

The external DC power cable (CABLE-RX-PWR) is used to connect a user-supplied power source to the HOBO RX3000 Monitoring Station to charge the station's internal battery. The external power source can be an intermittent power source, such as a 6W or larger solar panel. The external power source must be able to supply 6W, but the average power used will be much less and depends on the number and type of sensors, logging interval, and the frequency of internet connections.



HOBO CABLE-RX-PWR Specifications

Specifications

Wires: Two internal 18-AWG, unstripped

Length: 1.83 m (6 ft) cable

External Power Source Requirements

Voltage: 5 V DC minimum to 17 V DC maximum

Minimum supply output power: 6 Watt (typical power used is much less)

Contact Us

Sales (8am to 5pm ET, Monday through Friday)

- ▶ Email sales@onsetcomp.com
- ▶ Call 1-508-759-9500
- ▶ In U.S. toll free 1-800-564-4377
- ▶ Fax 1-508-759-9100

Technical Support (8am to 6pm ET, Monday through Friday)

- ▶ Contact Product Support www.onsetcomp.com/support/contact
- ▶ Call 1-508-759-9500
- ▶ In U.S. toll free 1-877-564-4377

Onset Computer Corporation
470 MacArthur Boulevard
Bourne, MA 02532