

In HOBOWare Pro, go to File, Preferences for PC, HOBOWare, Preferences on Mac



Go to Data Nodes, Data Storage to locate the current location of your database. Be sure to copy it to the same location on your new computer

