

CABLE-RX-PWR

## External DC Power Cable for RX3000

To connect a user-supplied power source to the HOBO RX3000 Monitoring Station to charge the station's internal battery.



### Contact Us

Sales (8am to 5pm ET, Monday through Friday)

- Email [sales@onsetcomp.com](mailto:sales@onsetcomp.com)
- Call 1-508-759-9500
- In U.S. toll free 1-800-564-4377
- Fax 1-508-759-9100

Technical Support (8am to 5pm ET, Monday through Friday)

- Contact Product Support [www.onsetcomp.com/support/contact](http://www.onsetcomp.com/support/contact)
- Call 1-508-759-9500
- In U.S. toll free 1-877-564-4377

Onset Computer Corporation  
470 MacArthur Boulevard  
Bourne, MA 02532

## External DC Power Cable for RX3000 (CABLE-RX-PWR) Specifications

### Specifications

**Wires:** Two internal 18-AWG, unstripped

**Length:** 1.83 m (6 ft) cable

### External Power Source Requirements

**Voltage:** 5 V DC minimum to 17 V DC maximum

**Minimum supply output power:** 6 Watt (typical power used is much less)