

Wiring Diagram

Monitoring:

- Energy Usage - kWh


Minimum required information:

- Voltage Max
- Number of Phases
- Voltage Phase to Phase
- Max Current per phase
- Configuration Wye or Delta

ZW-008 2 Analog 2 Pulse input node
(or ZW-005 Four Channel Data Node)



CABLE-2.5-STEREO



CT labels oriented towards power source



ZW- RCVR

PC or Mac running HOBOSware



For Alarms to cell phones or emails the computer must be connected to the internet.